

Why Do Septic Systems Fail?

J.A. Moore

-
- *Does sewage back up into your house?*
 - *Is there a wet, smelly spot in your yard that is difficult to mow?*
 - *Is your septic tank piped to a road ditch, storm sewer, or stream, or connected to farm drain tile?*
-

If you answered *yes* to any of these questions, your septic system is designed improperly or failing. It is not treating and disposing of sewage in a safe, sanitary manner.

In a properly operating septic system, the solid material in the sewage is settled out in a septic tank and stored until removal by pumping. The effluent from the tank is still sewage. It has a strong odor and is high in disease-causing organisms. This effluent is treated and absorbed in a soil absorption (or leach) field.

No matter what the cause, septic system failure is a nuisance and a health hazard that should be corrected promptly. Failures can result in the spread of serious disease and pollution of wells, lakes, and streams. Some of the more common reasons for septic system failure are discussed here. These failures can be attributed to several causes. A trained sanitarian should diagnose the problem and make recommendations for corrective action.

Using too much water

Using more water than the soil can absorb is the most common reason for failure. The sewage is forced to the surface or backs up into the house. This problem often is the result of one of two things:

- Improper design of the system
- A change in water use habits, such as an increase in the size of the

family or the addition of a water-using appliance

Surface water draining from roofs, driveways, and roads onto the soil absorption field area can put an extra load on the system. If the soil is saturated with clean water, even seasonally, it cannot accept any more wastewater. The untreated wastewater either will rise to the surface or back up.

Physical damage

Driving, parking, or building on top of a soil absorption unit can damage the field. Pipes can shift or be crushed, and the soil can be compacted. Damage of this sort can make it difficult to locate the septic tank and prevents access for regular pumping.

Tree roots also can clog the soil absorption field. Plant the area in grass, not trees or shrubs.

Improper design and construction

Improperly designed and/or constructed septic systems are doomed from the start. These systems usually fail in a few months because they are sized inadequately, installed in impermeable soils, or not constructed properly. In Oregon, several inches of unsaturated soil must be present beneath the soil absorption system to a limiting layer. Temporary or permanent

water tables, bedrock, or impervious soil all are considered limiting layers.

The soil is the most important part of the septic system and must be evaluated and protected properly. If the soil layer is too thin, the wastewater will not be treated before it enters the groundwater.

If the soil is too tight, it will not absorb all the wastewater, forcing it to the surface. The soil profile should be evaluated by a local health department sanitarian or a registered soil scientist to ensure that it's appropriate for wastewater treatment and disposal.

When constructing a septic system, it's essential that all components of the soil absorption field be level. If a line lies at too steep a grade or if the distribution system is not level, the wastewater will not be evenly distributed to all portions of the soil absorption field. This may overload one part of the field.

The heavy equipment used in home construction can compact the soil. During construction of the house, the area designated for the soil absorption system as well as the required replacement area and the area directly downhill should be fenced off to keep out heavy vehicles. Also, constructing and excavating a system during periods of high soil moisture can result in excessive soil smearing and compaction.

James A. Moore, Extension agricultural engineer, Oregon State University.



Lack of maintenance

The septic tank should be pumped about every 3 years to remove the sludge and scum retained in the tank and prevent clogging of the soil absorption field. More frequent pumping is needed if a garbage disposal is used in the home. Biological and chemical septic tank additives are not necessary and do not eliminate the need for pumping.

A septic tank is equipped with baffles at both the inlet and outlet. The inlet baffle prevents short-circuiting of the sewage, and the outlet baffle prevents the floatable scum from moving out into the soil absorption field. In time, these baffles can deteriorate and drop off into the tank. The condition of the baffles should be checked when the tank is being pumped. Replace those in poor condition with sanitary tees.

Corrective action

Any repair or new installation of a septic system must be approved by the local sanitarian, and a permit must be issued by the local health department.

Water conservation reduces the amount of water the absorption field must accept. It also reduces the flow through the septic tank, allowing more time for solids to settle out. Water conservation can prolong the life of any soil absorption system.

Install additional lines of soil absorption field to increase the size and capacity of the soil absorption system to accept wastewater. Or, you can plug one line, diverting all of the

wastewater into the remaining lines for at least 1 year. The next year a different line can be plugged, and the rested line reopened. In this way, you can rest one line each year, thus regaining capacity to accept and treat wastewater in the soil.

Repair physical damage such as leveling the distribution box or repairing crushed or broken pipe to restore the system. Tree roots interfering with the operation of the soil absorption field must be removed.

Improve surface and subsurface drainage by diverting all surface and groundwater away from the soil absorption field. The soil must absorb all the wastewater from the house. Surface and groundwater only add to the load.

When a system fails

- *Do not* place more soil over a surfacing soil absorption field; this does not fix the system and it will soon surface again.
- *Do not* pipe the sewage to the road ditch, storm sewer, stream, or a farm drain tile. Doing this pollutes the water and creates a health hazard.
- *Do not* run the sewage into a sink hole or drainage well. This pollutes the groundwater.
- *Do not* wait for the system to fail before pumping the septic tank. Once a system fails, it's usually too late to pump the tank. In some cases corrective measures are not enough—a new system must be constructed.

A properly designed, constructed, and maintained septic system can treat wastewater effectively for many years. For more information on septic systems, contact your county office of the OSU Extension Service or your local health department.

Related OSU Extension publications

Holding Tanks, EC 1342 (Reprinted 1992). No charge.

Septic Tank Maintenance, EC 1343 (Reprinted 1997). No charge.

Septic Tank-Soil Absorption Systems, EC 1341 (Reprinted 1993). 50¢

Ordering instructions

To order copies of the above publications or additional copies of EC 1340, *Why Do Septic Systems Fail?*, write or fax:

Publication Orders
Extension & Station Communications
Oregon State University
422 Kerr Administration
Corvallis, OR 97331-2119
Fax: 541-737-0817

You may order up to six no-charge publications without charge. If you request seven or more no-charge publications, include 25 cents for each publication beyond six.

World Wide Web

Our Educational Materials catalog and many of our publications are available on the Web at eesc.orst.edu

This publication was produced and distributed in furtherance of the Acts of Congress of May 8 and June 30, 1914. Extension work is a cooperative program of Oregon State University, the U.S. Department of Agriculture, and Oregon counties.

Oregon State University Extension Service offers educational programs, activities, and materials—*without regard to race, color, religion, sex, sexual orientation, national origin, age, marital status, disability, and disabled veteran or Vietnam-era veteran status*—as required by Title VI of the Civil Rights Act of 1964, Title IX of the Education Amendments of 1972, and Section 504 of the Rehabilitation Act of 1973. Oregon State University Extension Service is an Equal Opportunity Employer.